



EcoSense Lighting Fixtures must be installed by a qualified electrician.

EcoSense Lighting, Inc. is not responsible if its fixtures are not installed in accordance with all national and local safety standards.

**INCLUDED IN BOX**

**Mounting Track With Mounting Track Clip Installation Guide**

**NOTE**

- Two mounting clips required for 1ft fixture and four mounting clips required for 4ft fixture. Mounting clips and track work the same for L35 and L50.

**INSTALL THE FIXTURES**

**Ensure power is OFF**

**Step 1:** Insert mounting clip into fixture mounting holes. Then push mounting clip pin into the clip to lock it in place.

**Step 2:** Screw mounting track to surface.

**Step 3:** Snap clip with fixture attached to the track.

